

Assembly Instructions - Tablet Floor Stand



Tools Required:

- 3 mm Hex Key (supplied)
- 5 mm Hex Key (supplied)
- 8 mm Hex Key (supplied)
- Thumb Screws and Security Screws (supplied)

Instructions:

1. Place Cone onto Plate.
2. Insert Post A into Cone.
3. Place bolt through bottom of plate and tighten with 8mm hex key.
4. Insert Post B into Post A and tighten.
5. Insert Post C into Post B and tighten.
6. Insert iPad Holder into Head and tighten with 5mm hex key.
7. Insert iPad into holder.
9. Use thumb screws or security screws to secure gate to holder and tighten with 3mm hex key.

