

Assembly Instructions - Toolbox Mount

Tools Required:

- (2) M6 Flat Head Screws (supplied)
- (1) M5 Allen Key (supplied)
- (1) M4 Allen Key (supplied)
- (1) M3 Allen key (supplied)
- Velcro Tape (supplied)

Instructions:

1. Remove handle from side of toolbox.
2. Mount post assembly to mounting plate using M6 flat head screws with M4 Allen key.
3. Bolt mounting plate to side of toolbox using the sliding washer. The bolts that were removed holding handle to tool box, are the same ones to be used to fasten this plate to the toolbox.
4. Slide bone assembly over post and adjust height and tighten knob.
5. Attach plate assembly to bone assembly and tighten set screw in side of head to lock using M5 Allen key.
6. Adjust friction by tightening set screw in top of head using M5 Allen key if required.
8. Mount laptop using supplied velcro tape.

